

# My Craft House

## **Iron on instructions**

Wash all fabrics with out softener before ironing shapes on.

1. Remove paper backing from shape.
2. Place shiny side down on the fabric.
3. Cover with a cloth, making sure your shape does not move.
4. Using a hot iron on a No2 or medium setting (no hotter) with NO STEAM. Press for 8 seconds for cotton less for other fabrics Remove iron and wait a few seconds then press again for 8 seconds.
5. Carefully remove cloth and check the edges to ensure they are fully stuck. If they are not, cover and press again. Repeat until fully stuck.

Fully machine washable on a cool wash.

If you find that the shapes start to lift simply re-iron with a cloth.

Please note that once these shapes are ironed onto fabric they **can not** be removed.

The adhesive used is Heat n Bond Ultrahold No Sew  
Do Not tumble dry, do not dry clean